MIXBOOK™
Quick Start Guide

ROSCO

1 Download the myMIX™ app to control MIXBOOK.

iOS

Android

2 Turn on MIXBOOK.

ON/OFF Button

3 Sign into your app and press "No Light Connected" to get started.

NO LIGHT CONNECTED

4 Press SCAN

Connect all   SCAN

* MIXBOOK-ADCE
* MIX-1882

**5** Click on MIXBOOK to connect to it.
MIXBOOK will not be visible if another device is connected to it. The current user can disconnect by pressing the 3 dots and choosing "Disconnect", or by pressing and holding the MIXBOOK name.

SELECT A LIGHT TO CONTROL IT ⌄

MIXBOOK-ADCE   ⋮

6 Click it again to enter live mode.

MIXBOOK-ADCE ⌄

MIXBOOK-ADCE   ⋮

For more information, download the full user manual on our website: **WWW.ROSCO.COM**   See other side for Tips & Tricks ▶

Tips & Tricks

- Rename your MIXBOOK by clicking on the 3 dots. By renaming MIXBOOK, you are only changing the name in your app. If another user connects to the same MIXBOOK, their app will show the original MIXBOOK name.

MIXBOOK

- Please note that effects are not available in MIXBOOK.

- It is always better to fully charge your MIXBOOK before the first usage. Allow it to charge for at least 3 hours the first time.

Key For Indicator Light On The Side Of MIXBOOK:

- No color: MIXBOOK is off
- Steady green: fully charged
- Blinking red slowly = battery level below 20%

- Blinking red quickly = empty battery
- Blinking blue = awaiting connection
- Steady blue = connected